



FITTING BRUSH RAILS INSTRUCTIONS FOR TOYOTA HILUX 2005-CURRENT

TUFF BULLBARS AUSTRALIA,
5-7 Holt Drive, (P.O. Box 1977)
Torrington,
Toowoomba,
Queensland 4350,
AUSTRALIA



Ph: **1300 BE TUFF** (1300 23 88 33)
Fax: 07 4633 1236
sales@tuffbullbars.com.au
admin@tuffbullbars.com.au
feedback@tuffbullbars.com.au
www.tuffbullbars.com.au

TOYOTA HILUX BRUSH RAILS - BOLT KIT

D/CAB	S/CAB	
4	4	12mm x 150mm threaded rod
8	4	12mm x 140mm threaded rod
24	16	12mm normal nuts
24	16	12mm spring washers
18	12	40mm x 10mm bolts
40	28	10mm flat washers
20	14	10mm Nylock Nuts
6	4	190mm Backing Plates
2	2	Spigot Bolts (10mm bolts)
6	4	Chassis brackets
6	4	Extension Brackets
		Options: Bolt On Spigots Double Rails =12 x 10mm bolts & nuts & washers Single Rails =6 x 10mm bolts & nuts & washers

www.tuffbullbars.com.au

1300 BE TUFF

TUFF BY NAME * TUFF BY NATURE

**AUSTRALIA'S LEADING BULLBAR
MANUFACTURER**





FITTING BRUSH RAILS INSTRUCTIONS FOR TOYOTA HILUX 2005-CURRENT



CLAMP BRACKETS TO CHASSIS (6 BRACKETS FOR DUAL CAB & 4 BRACKETS FOR SINGLE CAB & EXTRA CAB)

BRACKETS ARE MOUNTED APPROX. 700MM, 1100MM & 1800MM FROM THE FRONT MUD FLAP



ATTACH - L SHAPED SLOTTED BRACKETS LOOSELY TO CHASSIS BRACKETS – BRACKETS POINT BACKWARDS

AS SHOWN IN PICTURE



SLIDE BRUSH RAILS ONTO SPIGOT/SPIGOTS ON BULLBAR



FITTING BRUSH RAILS INSTRUCTIONS FOR TOYOTA HILUX 2005-CURRENT



ALIGN RAIL – STEP LEVEL (USE A JACK TO HOLD STEP UP)

FIT BOLTS FROM STEP TO SLOTTED L BRACKETS, TIGHTEN & ALIGN ALL BRACKETS

DRILL DOWN FOR BOLT HOLE



DRILL AN 11MM HOLE VERTICALLY THROUGH TOP OF RAIL & SPIGOT & INSERT BOLT & TIGHTEN TO FASTEN RAIL TO SPIGOT

PLEASE DON'T HESITATE TO CALL US ON **1300 BE TUFF** (1300 23 88 33) IF YOU HAVE ANY PROBLEMS WITH FITTING

BEST REGARDS, THE TUFF TEAM! 😊