



FITTING INSTRUCTIONS FOR TOYOTA LAND CRUISER 75/78/79 SERIES BRUSH RAILS

TUFF BULLBARS AUSTRALIA,
6 Tews CT, (P.O. Box 1977)
Torrington,
Toowoomba,
Queensland 4350,
AUSTRALIA



Ph: **1300 BE TUFF** (1300 23 88 33)
Fax: 07 4633 1236
sales@tuffbullbars.com.au
admin@tuffbullbars.com.au
feedback@tuffbullbars.com.au
www.tuffbullbars.com.au

TOYOTA LAND CRUISER 75/78/79 SERIES BRUSH RAILS - BOLT KIT

S/CAB	
8	120mm x 12mm threaded rod
16	12mm normal nuts
16	12mm spring washers
12	40mm x 10mm bolts
28	10mm flat washers
14	10mm Nylock Nuts
4	190mm Backing Plates
2	Spigot Bolts (10mm bolts)
4	Chassis brackets
4	Extension Brackets
	Options: Bolt On Spigots Double Rails =12 x 10mm bolts & nuts & washers Single Rails =6 x 10mm bolts & nuts & washers

www.tuffbullbars.com.au

1300 BE TUFF

TUFF BY NAME * TUFF BY NATURE

**AUSTRALIA'S LEADING BULLBAR
MANUFACTURER**





FITTING INSTRUCTIONS FOR TOYOTA LAND CRUISER 75/78/79 SERIES BRUSH RAILS



Driver side FRONT bracket – fits around the exhaust as shown



Passenger side bracket –
Sits +/- 10 mm off exhaust



IMPORTANT – START WITH DRIVERS SIDE!
Drivers side front bracket – fits around the exhaust as shown



FITTING INSTRUCTIONS FOR TOYOTA LAND CRUISER 75/78/79 SERIES BRUSH RAILS



Driver side REAR bracket



Passenger side FRONT bracket



Slide brush rail onto spigot on the
bullbar



FITTING INSTRUCTIONS FOR TOYOTA LAND CRUISER 75/78/79 SERIES BRUSH RAILS



Fit step to brackets. Make sure step is level and follows the vehicle line (Use jack to hold up step if necessary)

Fasten with 10 mm bolts and washers



Drill an 11 mm hole vertically through the top of the rail and spigot and insert bolt. Using 10 mm bolts, nuts and washers, tighten to fasten and secure.

PLEASE DON'T HESITATE TO CALL US ON **1300 BE TUFF** (1300 23 88 33) IF YOU HAVE ANY PROBLEMS WITH FITTING

BEST REGARDS, THE TUFF TEAM! 😊