



FITTING INSTRUCTIONS FOR TOYOTA PRADO 120 SERIES BRUSH RAILS

TUFF BULLBARS AUSTRALIA,
5-7 Holt Drive, (P.O. Box 1977)
Torrington,
Toowoomba,
Queensland 4350,
AUSTRALIA



Ph: **1300 BE TUFF** (1300 23 88 33)
Fax: 07 4633 1236
sales@tuffbullbars.com.au
admin@tuffbullbars.com.au
feedback@tuffbullbars.com.au
www.tuffbullbars.com.au

TOYOTA PRADO 120 SERIES BRUSH RAILS - BOLT & BRACKET KIT

WAGON	
8	150mm x 12mm threaded rod
16	12mm Normal nuts
16	12mm spring washers
12	40mm x 10mm bolts
28	10mm flat washers
14	10mm Nylock Nuts
4	215mm backing plates
2	Spigot Bolts (10mm bolts)
4	Chassis brackets
4	Extension Brackets
	Options: Bolt On Spigots Double Rails =12 x 10mm bolts & nuts & washers Single Rails =6 x 10mm bolts & nuts & washers

www.tuffbullbars.com.au

1300 BE TUFF

TUFF BY NAME * TUFF BY NATURE

**AUSTRALIA'S LEADING BULLBAR
MANUFACTURER**





FITTING INSTRUCTIONS FOR TOYOTA PRADO 120 SERIES BRUSH RAILS



Remove existing step



Picture shown is Front and rear brackets for each side of the vehicle



Bolt brackets to chassis

The front bracket sits +/- 680mm from the front mud flap

The rear bracket sits +/-1480mm from the front mud flap



FITTING INSTRUCTIONS FOR TOYOTA PRADO 120 SERIES BRUSH RAILS



Attach L-shaped slotted brackets to the chassis brackets

Brackets point backwards

TIP: tighten loosely and horizontally before fitting step



Slide brush rail onto spigots on the bullbar



Fit steps and bolt to L-shaped brackets

Make sure step is level and follows the vehicle line (use jack to hold up if necessary)



FITTING INSTRUCTIONS FOR TOYOTA PRADO 120 SERIES BRUSH RAILS



Drill 11mm hole vertically through the top of the rail and spigot and insert bolt – using 10mm bolts, nuts and washers, tighten to fasten and secure



PLEASE DON'T HESITATE TO CALL US ON **1300 BE TUFF** (1300 23 88 33) IF YOU HAVE ANY PROBLEMS WITH FITTING

BEST REGARDS, THE TUFF TEAM! 😊