



FITTING INSTRUCTIONS FOR VW AMAROK 2011 BRUSH RAILS

TUFF BULLBARS AUSTRALIA,
5-7 Holt Drive, (P.O. Box 1977)
Torrington,
Toowoomba,
Queensland 4350,
AUSTRALIA



Ph: **1300 BE TUFF** (1300 23 88 33)

Fax: 07 4633 1236

sales@tuffbullbars.com.au

admin@tuffbullbars.com.au

feedback@tuffbullbars.com.au

www.tuffbullbars.com.au

VW AMAROK BRUSH RAILS - BOLT & BRACKET KIT

D/CAB	S/CAB	
4	0	150mm x 12mm threaded rod
8	8	140mm x 12mm threaded rod
24	16	12mm normal nuts
24	16	12mm spring washers
2	2	50mm x 12mm bolts
4	4	12mm flat washers
2	2	50mm x 50mm square plates
2	2	12mm Nylock Nuts
18	12	40mm x 10mm bolts
20	14	10mm Nylock Nuts
40	28	10mm Flat washers
2	2	190mm Backing Plates
2	-	215mm Backing Plates
2	2	140mm Threaded Backing Plates
2	2	Spigot Bolts (10mm bolts)
6	4	Chassis brackets
6	4	Extension Brackets
		Options: Bolt On Spigots Double Rails =12 x 10mm bolts & nuts & washers Single Rails =6 x 10mm bolts & nuts & washers

www.tuffbullbars.com.au

1300 BE TUFF

TUFF BY NAME * TUFF BY NATURE





FITTING INSTRUCTIONS FOR VW AMAROK 2011 BRUSH RAILS



Front sets of brackets



Middle sets of brackets



Rear sets of brackets



FITTING INSTRUCTIONS FOR VW AMAROK 2011 BRUSH RAILS



Attach the L-shaped slotted brackets

Brackets point backwards

TIP: Tighten loosely and horizontal before fitting step

Bolt brackets around the chassis with treaded rods & backing plates

The front bracket sits 160mm from the front mud flap

The middle bracket sits 900mm from the front flap

The back bracket sits 1700mm from the front flap



Slide brush rail onto spigots on the bullbar



FITTING INSTRUCTIONS FOR VW AMAROK 2011 BRUSH RAILS



Fit steps and bolt to L-shaped brackets

Make sure step is level and follows the vehicle line (Use jack to hold up if necessary)



Drill an 11mm hole vertically through the top of the rail and spigot and insert bolt – using 10mm bolts, nuts and washers, tighten to fasten and secure



FITTING INSTRUCTIONS FOR VW AMAROK 2011 BRUSH RAILS



PLEASE DON'T HESITATE TO CALL US ON **1300 BE TUFF** (1300 23 88 33) IF YOU
HAVE ANY PROBLEMS WITH FITTING

BEST REGARDS, THE TUFF TEAM! 😊